

































①天板サイド(前) × 1 	②天板サイド(後) × 1 	③天板 × 1 	④左側板 × 1 	⑤中央板 × 1 	⑥右側板 × 1 
⑦可動棚(大) × 1 	⑧可動棚(小) × 2 	⑨左側観音扉 × 1 	⑩右側観音扉 × 1 	⑪左側留め具 × 2 	⑫右側留め具 × 2 
⑬固定棚 × 1 	⑭底板 × 1 	⑮左側背面板 × 1 	⑯右側背面板 × 1 	A.ネジ × 10 (予備2個) 	B.カムロック × 6  (ボルト) (受け)
C.マグネット × 1  C専用ネジ × 4 	D.留め具用ストッパー × 4  D専用ネジ × 16 (予備2個) 	E.ピボット × 4 	F.棚ダボ × 12 (予備2個) 	G.ネジ隠しシール × 12 (予備2個) 	H.丁番 × 8  H専用ネジ × 48 (予備2個) 
I.キャスター × 3 (ストッパー無)  I・J専用ネジ × 20 (予備2個) 	J.キャスター × 2 (ストッパー付き) 	K.ボンド × 1 	L.背面ストッパー × 8  L専用ネジ × 8 